




Samsung HD Pro LED Light Ring Replacement

This guide will show you how to replace the LED Light Ring in the camera.

Written By: AllisonBridges





TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Casing




- Locate a small opening around the front panel of the camera.

Step 2




- Using a plastic opening tool, apply pressure to various points around the camera to pry open the front panel.

Step 3



- Remove both of the connecting wires from the motherboard.
- Be careful to not bend headers or damage the wires.

Step 4



- Apply a plastic opening tool to the gray plastic band around the case of the camera. Insert the edge of the spudger between the case of the camera and the gray plastic band.

Step 5




- Apply pressure with the plastic opening tool to various areas of the gray plastic band to pry it from the white plastic back of the case.

Step 6 — LED Light Ring



- Locate the small circuit board surrounding the lens in the removed front portion of the device.

Step 7



- Push the four white tabs away from the center of the lens housing while pulling the led ring up near each tab.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-07 11:32:19 PM.